



## VB-5 Installation:

### Preparation:

- Locate source of rattle to be eliminated.
- Be sure to clean the surface of automotive body panels by washing thoroughly with warm, soapy water to remove any dirt or dust particles. CAE recommends cleaning the surface once more with an ammonia based, aerosol glass cleaner to remove unwanted wax and grease.
- Allow surface to dry completely before applying VB-5.



### Installation:

- Cut VB-5 into strips the size of the area to be treated.
- Simply peel and remove release liner from VB-5 and apply to the prepared surface.
- Application of VB-5 will effectively decouple surfaces and prevent rattles caused from vibration from occurring.



### **TOOLS**

Scissors or a razor knife

Please Note:  
Product must be installed within one year for best performance.

  
CASCADE AUDIO ENGINEERING  
PH: 541-389-6821 - FX: 541-389-5273  
sales@cascadeaudio.com  
www.cascadeaudio.com