



## VB-3 Barrier Installation:

### Preparation:

- For best results, take measurements of area to be treated before any modification to VB-3 roll. For an exact fit, the factory undercarpet padding works well as a template when tracing and cutting VB-3.
- VB-3 may be cut with either scissors or a razor knife.



### Installation:

- Mold the material into place by hand.
- Installation of VB-3 may require the use of several pieces of material to cover the surface of the floorpan. For maximum performance, be sure to fit materials together closely to produce “tight” seams. This will further impede the passage of low frequency road noise. Duct tape may be used to adhere pieces together.
- Complete the installation by removing excess material over seat bolt/ belt locations.
- Securing VB-3 to the floorpan is not required.



### TOOLS

Factory carpet padding to use as a template  
Scissors or a razor knife



CASCADE AUDIO ENGINEERING  
PH: 541-389-6821 - FX: 541-389-5273  
sales@cascadeaudio.com  
www.cascadeaudio.com